
























































Original	Replacement	Original	Replacement
 Power	 Power	 >>/>>  / Tun+ / Right	 >>
 EQ	 Dual	 <</ << / Tun- / Left	 <<
 >>/>>  / Tun+ / Right	 >>	 Stop / OK	 Stop
 <</ << / Tun- / Left	  <<	 Stop / OK	 Ok
 Preset/Folder Up	 Ch +	 Play/Pause /	 Play
 Preset/Folder	 Ch -	 Play/Pause /	 Down
 Function	 Menu	 Play/Pause /	 Pause
 Vol+	 Vol +	 Rec	 Rec
 Vol-	 Vol -	 RDS	 Smart
 Mute	 Mute	 PTY	 Media
 Sleep	 Sleep		
 Info	 Info		
 Repeat/Random /	 Up		
 Repeat/Random /	 Text		
 Program/Memo	 D. Menu		
 >>/>>  / Tun+ / Right	 Right		
 <</ << / Tun- / Left	 Left		

