

















































































Original		Replacement		Original		Replacement	
	Power		Power		Home/Recent		Smart
	1		1		Guide		Guide
	2		2		Back		Back
	3		3		Exit		Exit
	4		4		Up		Up
	5		5		Down		Down
	6		6		Right		Right
	7		7		Left		Left
	8		8		OK		Ok
	9		9		Wheel Up		>>
	0		0		Wheel Down		<<
	List		List		3D		3D
	Vol+		Vol +		Source		AV
	Vol-		Vol -		*		Options
	Mute		Mute		<<		<<
	CH+		Ch +		Play		Play
	CH-		Ch -		>>		>>





Original	Replacement	Original	Replacement
 Pause	 Pause		
 Red	 Red		
 Green	 Green		
 Yellow	 Yellow		
 Blue	 Blue		

