



























































































| Original  |                | Replacement   |                  | Original  |               | Replacement   |                           |
|---|----------------|---|------------------|---|---------------|---|---------------------------|
|    | Power          |    | Power            |    | 0             |    | 0                         |
|    | Open/Close     |    | Eject / Surround |    | Title         |    | Shift + Sound / Title     |
|    | Home           |    | Shift + Menu /   |    | Marker        |    | Fav / Marker / PC         |
|    | FM/AM          |    | Shift + 6        |    | Search        |    | Red / Netflix / Search    |
|    | AV             |    | AV / Input / RDS |    | Zoom          |    | Zoom / Size               |
|    | PIP            |    | Picture / Format |    | Audio/Mo./St. |    | Audio / Lang I/II         |
|    | 1              |    | 1                |    | Sound         |    | Sound / Title             |
|    | 2              |    | 2                |    | XTS Pro       |    | Shift + Audio / Lang I/II |
|    | 3              |    | 3                |    | Level/Delay   |    | Smart / List              |
|    | Test Tone      |    | Text / Goto      |    | Menu/List     |    | Menu / Home               |
|   | 4              |   | 4                |   | PR/Preset+    |   | CH+ / Page+               |
|  | 5              |  | 5                |  | Up            |  | Up                        |
|  | 6              |  | 6                |  | Setup         |  | Setup / OPT /             |
|  | [...]/Subtitle |  | Subtitle / EQ    |  | Left/Tun-     |  | Left                      |
|  | 7              |  | 7                |  | Memory/Enter  |  | OK                        |
|  | 8              |  | 8                |  | Right/Tun+    |  | Right                     |
|  | 9              |  | 9                |  | Display       |  | Display / Media           |





| Original  | Replacement  |
|---|--|
|  PR/Presets- |  CH- / Page-                    |
|  Down        |  Down                           |
|  Return      |  Back / Return                  |
|  I<</Skip-   |  I<< / Preset-                  |
|  >>I/Skip+   |  >>I / Preset+                  |
|  Vol+        |  Vol+                           |
|  <</Scan-    |  << / Tune-                     |
|  >>/Scan+    |  >> / Tune+                     |
|  Vol-        |  Vol-                           |
|  Pause/Step  |  Pause / Step / Freeze          |
|  Play       |  Play / Slow                   |
|  Stop      |  Stop / Hold                  |
|  Rec       |  Rec / Rec Mode               |
|  Rec Mode  |  Shift + Rec / Rec Mode      |
|  Timer Rec |  Sleep / Timer                |
|  Mute      |  Mute / Dimmer                |
|  Dubbing   |  Blue / Prime Video / Random |

| Original   | Replacement  |
|--|--|
|  CHP ADD        |  Shift + Fav / Marker / PC  |
|  Repeat         |  Green / APP / Repeat       |
|  Repeat A/B     |  Yellow / YouTube / Repeat  |
|  Thumbnail      |  Shift + Guide / EPG / -/-- |
|  Timeshift      |  Info / Angle               |
|  Instant Skip   |  Guide / EPG / -/--         |
|  Clear          |  Exit / Cancel / Clear      |
|  RDS/Resolution |  Shift + AV / Input / RDS   |
|  PTY            |  D.Menu / Top               |
|  ShowView       |  Shift + Smart / List       |
|  Tv/DVD        |  TV/ Radio /               |

