


























































































| Original  | Replacement   |
|---|---|
|  Power |  Power     |
|  Mute  |  Mute      |
|  TV    |  Shift + 1 |
|  REC   |  Shift + 2 |
|  DVD   |  Shift + 3 |
|  Audio |  Shift + 4 |
|  Timer |  AV        |
|  Zoom  |  Eject     |
|  Audio |  Dual      |
|  1    |  1        |
|  2   |  2       |
|  3   |  3       |
|  4   |  4       |
|  5   |  5       |
|  6   |  6       |
|  7   |  7       |
|  8   |  8       |

| Original   | Replacement   |
|--|---|
|  9            |  9       |
|  0/AV         |  0       |
|  EPG/Music-ID |  Guide   |
|  Media        |  Media   |
|  PIP/Input    |  Format  |
|  Text/Disc-M  |  Text    |
|  Menu/Title   |  Menu    |
|  End          |  Exit    |
|  Info         |  Info    |
|  V+          |  Vol +  |
|  V-         |  Vol - |
|  P+         |  Ch +  |
|  P-         |  Ch -  |
|  Up         |  Up    |
|  Down       |  Down  |
|  Right      |  Right |
|  Left       |  Left  |





































































| Original   | Replacement | Original   | Replacement |
|--|-------------|--|-------------|
|   | OK          |   | Ok          |
|   | Red         |   | Red         |
|   | Green       |   | Green       |
|   | Yellow      |   | Yellow      |
|   | Blue/Marker |   | Blue        |
|   | <<          |   | <<          |
|   | Play        |   | Play        |
|   | >>          |   | >>          |
|   | Rec/Back    |   | Rec         |
|   | Pause       |   | Pause       |
|  | Stop        |  | Stop        |
|  |             |  |             |
|  |             |  |             |
|  |             |  |             |
|  |             |  |             |
|  |             |  |             |
|  |             |  |             |
|  |             |  |             |
|  |             |  |             |
|  |             |  |             |
|  |             |  |             |
|  |             |  |             |
|  |             |  |             |






































| Original  | Replacement   |
|---|---|
|  Power |  Power     |
|  Mute  |  Mute      |
|  TV    |  Shift + 1 |
|  REC   |  Shift + 2 |
|  DVD   |  Shift + 3 |
|  Audio |  Shift + 4 |
|  Timer |  AV        |
|  Zoom  |  Eject     |
|  Audio |  Dual      |
|  1    |  1        |
|  2   |  2       |
|  3   |  3       |
|  4   |  4       |
|  5   |  5       |
|  6   |  6       |
|  7   |  7       |
|  8   |  8       |


































| Original   | Replacement   |
|--|---|
|  9            |  9       |
|  0/AV         |  0       |
|  EPG/Music-ID |  Guide   |
|  Media        |  Media   |
|  PIP/Input    |  Format  |
|  Text/Disc-M  |  Text    |
|  Menu/Title   |  Menu    |
|  End          |  Exit    |
|  Info         |  Info    |
|  V+          |  Vol +  |
|  V-         |  Vol - |
|  P+         |  Ch +  |
|  P-         |  Ch -  |
|  Up         |  Up    |
|  Down       |  Down  |
|  Right      |  Right |
|  Left       |  Left  |








































| Original  | Replacement   |
|---|---|
|  Power |  Power     |
|  Mute  |  Mute      |
|  TV    |  Shift + 1 |
|  REC   |  Shift + 2 |
|  DVD   |  Shift + 3 |
|  Audio |  Shift + 4 |
|  Timer |  AV        |
|  Zoom  |  Eject     |
|  Audio |  Dual      |
|  1    |  1        |
|  2   |  2       |
|  3   |  3       |
|  4   |  4       |
|  5   |  5       |
|  6   |  6       |
|  7   |  7       |
|  8   |  8       |



































| Original   | Replacement   |
|--|---|
|  9            |  9       |
|  0/AV         |  0       |
|  EPG-Music-ID |  Guide   |
|  Media        |  Media   |
|  PIP/Input    |  Format  |
|  Text/Disc-M  |  Text    |
|  Menu/Title   |  Menu    |
|  End          |  Exit    |
|  Info         |  Info    |
|  V+          |  Vol +  |
|  V-         |  Vol - |
|  P+         |  Ch +  |
|  P-         |  Ch -  |
|  Up         |  Up    |
|  Down       |  Down  |
|  Right      |  Right |
|  Left       |  Left  |







| Original  | Replacement   |
|---|---|
|  Power |  Power     |
|  Mute  |  Mute      |
|  TV    |  Shift + 1 |
|  REC   |  Shift + 2 |
|  DVD   |  Shift + 3 |
|  Audio |  Shift + 4 |
|  Timer |  AV        |
|  Zoom  |  Eject     |
|  Audio |  Dual      |
|  1    |  1        |
|  2   |  2       |
|  3   |  3       |
|  4   |  4       |
|  5   |  5       |
|  6   |  6       |
|  7   |  7       |
|  8   |  8       |

| Original   | Replacement   |
|--|---|
|  9            |  9       |
|  0/AV         |  0       |
|  EPG/Music-ID |  Guide   |
|  Media        |  Media   |
|  PIP/Input    |  Format  |
|  Text/Disc-M  |  Text    |
|  Menu/Title   |  Menu    |
|  End          |  Exit    |
|  Info         |  Info    |
|  V+          |  Vol +  |
|  V-         |  Vol - |
|  P+         |  Ch +  |
|  P-         |  Ch -  |
|  Up         |  Up    |
|  Down       |  Down  |
|  Right      |  Right |
|  Left       |  Left  |



