




































	Original	Replacement		Original	Replacement
	Power		Power		<< Rev
	Open / Close		Eject		>> Fwd
	Language		Dual		I<< Prev
	Angle		Format		>>I Next
	Subtitle		Subt		Menu
	Prog		Sleep		Title
	1		1		Up
	2		2		Right
	3		3		Down
	4		4		Left
	5		5		Enter
	6		6		Time
	7		7		Setup
	8		8		PBC
	9		9		Vol +
	0/10		0		Vol -
	10+		Guide		Zoom
					Shift + Guide
					Vol +
					Vol -
					Shift + Eject





Original	Replacement
Return	Back
A-B	D. Menu
Repeat	Text
P-Scan	Media
Step	Shift + Pause
Slow	Shift + Play
N/P	Red
L/R	Green
Mute	Mute
Display	Info
Play/Pause	Play
Stop	Stop
Play/Pause	Pause
Default	Smart

Original	Replacement

