







































































Original	Replacement
 PP	 Back / Return
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 P<P	 Fav / Marker / PC
 0	 0
 --	 Guide / EPG / -/--
 Menu [M]	 Menu / Home
 Info [i]	 Info / Angle
 I-II	 Audio / Lang I/II

Original	Replacement
 Mute	 Mute / Dimmer
 Left	 Left
 Up	 Up
 Right	 Right
 OK	 OK
 Down	 Down
 V -	 Vol-
 V +	 Vol+
 P -	 CH- / Page-
 P +	 CH+ / Page+
 Red / Sound	 Red / Netflix / Search
 Red / Sound	 Sound / Title
 Green / Picture	 Green / APP / Repeat
 Green / Picture	 Picture / Format
 Yellow / Feature	 Yellow / YouTube / Repeat
 Blue / Install	 Blue / Prime Video / Random
 Text	 Text / Goto





	Original	Replacement		Original	Replacement
	[≡o]	<b>TIMER SLEEP</b>	Sleep / Timer		
	Hold	<b>HOLD</b>	Stop / Hold		
	[≡X]	<b>EXIT CANCEL</b>	Exit / Cancel / Clear		
	Mix / PIP Swap	<b>LIST SMART</b>	Smart / List		
	PIP / Size	<b>SIZE ZOOM</b>	Zoom / Size		
	PIP Down / [≡?]	<b>PRESET-</b>	I<< / Preset-		
	PIP Up / Index	<b>PRESET+</b>	>>I / Preset+		
	[TV]	<b>PROGRAM TV/RADIO</b>	TV/Radio /		
	[AV]	<b>RDS AV INPUT</b>	AV / Input / RDS		

