




































Original	Replacement
	 Power
	 Smart / List
	 Text / Goto
	 Mute / Dimmer
	 Vol+
	 Vol-
	 Info / Angle
	 Guide / EPG / -/-
	 Play / Slow
	 Pause / Step / Freeze
	 Stop / Hold
	 Menu / Home
	 Exit / Cancel / Clear
	 AV / Input / RDS
	 TV/Radio /
	 Up
	 CH+ / Page+

Original	Replacement
	 Down
	 CH- / Page-
	 Left
	 Right
	 OK
	 Back / Return
	 Zoom / Size
	 1
	 2
	 3
	 4
	 5
	 6
	 7
	 8
	 9
	 0





Original	Replacement	Original	Replacement
<<	<< / Tune-		
>>	>> / Tune+		
<<	<< / Preset-		
>>	>>  / Preset+		
Fav	Fav / Marker / PC		
RGB	Setup / OPT /		
Audio	Audio / Lang I/II		
Lang	+  Shift + Audio / Lang I/II		
Red/Repeat	Red / Netflix / Search		
Green/A-B	Green / APP / Repeat		
Yellow/Zoom	Yellow / YouTube / Repeat		
Blue/Subtitle	Blue / Prime Video / Random		

