















| Original | | Replacement | | Original | | Replacement | |
|---|----------|---|-----------------------------|---|-------|---|-----------------------|
|  | Power |  | Power |  | >> |  | >> / Tune+ |
|  | Mute |  | Mute / Dimmer |  | Menu |  | Menu / Home |
|  | Red |  | Red / Netflix / Search |  | Up |  | Up |
|  | Green |  | Green / APP / Repeat |  | Back |  | Back / Return |
|  | Yellow |  | Yellow / YouTube / Repeat |  | Left |  | Left |
|  | Blue |  | Blue / Prime Video / Random |  | OK |  | OK |
|  | Internet |  | Smart / List |  | Right |  | Right |
|  | Source |  | AV / Input / RDS |  | i |  | Info / Angle |
|  | Lang |  | Audio / Lang I/II |  | Down |  | Down |
|  | Tv/Radio |  | TV/Radio / |  | Exit |  | Exit / Cancel / Clear |
|  | Subtitle |  | Subtitle / EQ |  | Vol+ |  | Vol+ |
|  | LIB |  | Picture / Format |  | P::P |  | Display / Media |
|  | Rec |  | Rec / Rec Mode |  | PR+ |  | CH+ / Page+ |
|  | Stop |  | Stop / Hold |  | Vol- |  | Vol- |
|  | << |  | << / Tune- |  | FAV |  | Fav / Marker / PC |
|  | Play |  | Play / Slow |  | PR- |  | CH- / Page- |
|  | Pause |  | Pause / Step / Freeze |  | 1 |  | 1 |





| Original | | Replacement | | Original | | Replacement | |
|----------|-------|-------------|--------------------|----------|--|-------------|--|
| | 2 | | 2 | | | | |
| | 3 | | 3 | | | | |
| | 4 | | 4 | | | | |
| | 5 | | 5 | | | | |
| | 6 | | 6 | | | | |
| | 7 | | 7 | | | | |
| | 8 | | 8 | | | | |
| | 9 | | 9 | | | | |
| | Text | | Text / Goto | | | | |
| | 0 | | 0 | | | | |
| | Guide | | Guide / EPG / -/-- | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |

