



























































































































































Original	Replacement	Original	Replacement
 POWER	 Power	 GAME / BLUE	 Blue / Prime Video / Random
 1	 1	 SLEEP / GREEN	 Green / APP / Repeat
 2	 2	 SLEEP / GREEN	 Sleep / Timer
 3	 3	 STATUS /	 Yellow / YouTube / Repeat
 4	 4	 PP/CANCEL	 Exit / Cancel / Clear
 5	 5	 P.S	 Display / Media
 6	 6	 MUTE	 Mute / Dimmer
 7	 7	 UP	 Up
 8	 8	 CH+	 CH+ / Page+
 9	 9	 TV/TEXT	 Text / Goto
 0	 0	 LEFT	 Left
 SUBPAGE	 Guide / EPG / -/--	 VOL-	 Vol-
 I/II	 Audio / Lang I/II	 MENU	 Menu / Home
 SWAP / RED	 Back / Return	 RIGHT	 Right
 SWAP / RED	 Red / Netflix / Search	 VOL+	 Vol+
 AV	 AV / Input / RDS	 DOWN	 Down
 FREEZE	 Pause / Step / Freeze	 CH-	 CH- / Page-

Original	Replacement	Original	Replacement
 DIMMER MUTE	 SHIFT	 TV	 DVD
 TV	 SAT	 SLOW	 STEP - FREEZE
 SLEEP	 AUX	 HOLD	 REC MODE
 SLEEP	 PRESET-	 TUNE+	 PRESET+
 STATUS /	 TUNE-	 TUNE-	 EQ
 PP/CANCEL	 LANG I/II	 TUNE+	 SURROUND
 P.S	 EQ	 TITLE	 SOUND
 MUTE	 YouTube	 LANG I/II	 AUDIO
 UP	 REPEAT A-B	 EQ	 SUBTITLE
 CH+	 CLEAR	 SURROUND	 TIMER
 TV/TEXT	 EXIT	 SOUND	 PROGRAM
 LEFT	 CANCEL	 FORMAT	 TV RADIO
 VOL-	 MEDIA DISPLAY	 PICTURE	 RDS
 MENU	 DIMMER MUTE	 ZOOM	 AV INPUT
 RIGHT	 MUTE	 OPT-TOOLS	 TOP MENU
 VOL+	 Up	 GOTO	 D.MENU
 DOWN	 CH+ / Page+	 TEXT	 SETUP
 CH-	 Text / Goto	 RETURN	 TEXT
	 Left	 INFO	 AV INPUT
	 Right	 HOME	 HOME
	 Down	 ANGLE	 MENU
	 CH- / Page-	BACK	 EXIT
		CLEAR	 CANCEL
		LIST	SMART
		RETURN	MEDIA
		BACK	DISPLAY
		EXIT	CH PAGE
		CANCEL	VOL
		CLEAR	TV
		EXIT	DVD
		CANCEL	CD - STB
		CLEAR	1
		EXIT	VIDEO
		CANCEL	2
		CLEAR	TAPE
		EXIT	3
		CANCEL	TUNER
		CLEAR	4
		EXIT	AUX - HDD
		CANCEL	5
		CLEAR	USB
		EXIT	6
		CANCEL	BLUETOOTH
		CLEAR	7
		EXIT	8
		CANCEL	HDMI - BAT
		CLEAR	9
		EXIT	PC
		CANCEL	0
		CLEAR	FAV MARKER
		EXIT	GUIDE EPG
		CANCEL	NETFLIX
		CLEAR	APP
		EXIT	YouTube
		CANCEL	Prime Video
		CLEAR	SEARCH
		EXIT	REPEAT
		CANCEL	REPEAT A-B
		CLEAR	RANDOM
		EXIT	Mandis SHOP
		CANCEL	www.mandis.tv



