















| Original  |            | Replacement   |                            | Original  |          | Replacement   |                       |
|---|------------|---|----------------------------|---|----------|---|-----------------------|
|    | Power      |    | Power                      |    | FAV      |    | Fav / Marker / PC     |
|    | Mute       |    | Mute / Dimmer              |    | PG+      |    | CH+ / Page+           |
|    | TV / STB   |    | Shift + TV/Radio / Program |    | PG-      |    | CH- / Page-           |
|    | TV / Radio |    | TV/Radio /                 |    | Vol+     |    | Vol+                  |
|    | DVR Info   |    | Shift + Info / Angle       |    | Vol-     |    | Vol-                  |
|    | SAT List   |    | Smart / List               |    | M / P    |    | D.Menu / Top          |
|    | 1          |    | 1                          |    | Up       |    | Up                    |
|    | 2          |    | 2                          |    | EPG      |    | Guide / EPG / -/-     |
|    | 3          |    | 3                          |    | Left     |    | Left                  |
|    | 4          |    | 4                          |    | OK       |    | OK                    |
|   | 5          |   | 5                          |   | Right    |   | Right                 |
|  | 6          |  | 6                          |  | Menu     |  | Menu / Home           |
|  | 7          |  | 7                          |  | Down     |  | Down                  |
|  | 8          |  | 8                          |  | Exit     |  | Exit / Cancel / Clear |
|  | 9          |  | 9                          |  | Info     |  | Info / Angle          |
|  | Audio      |  | Audio / Lang I/II          |  | V-Format |  | Picture / Format      |
|  | 0          |  | 0                          |  | Recall   |  | Back / Return         |





|  | Original  | Replacement | Original  | Replacement                 |
|--|---|-------------|---|-----------------------------|
|  |    | Zoom        |    | Zoom / Size                 |
|  |    | Red         |    | Red / Netflix / Search      |
|  |    | Green       |    | Green / APP / Repeat        |
|  |    | Yellow      |    | Yellow / YouTube / Repeat   |
|  |    | Blue        |    | Blue / Prime Video / Random |
|  |    | ◀◀ FB       |    | << / Tune-                  |
|  |    | ▶▶ FF       |    | >> / Tune+                  |
|  |    | ◀◀ REV Slow |    | Shift + << /                |
|  |    | ▶▶ Slow     |    | Shift + >> /                |
|  |    | ● Record    |    | Rec / Rec Mode              |
|  |   | ▶ Play      |   | Play / Slow                 |
|  |  | Pause       |  | Pause / Step / Freeze       |
|  |  | ■ Stop      |  | Stop / Hold                 |
|  |  | Find        |  | Shift + Red / Netflix /     |
|  |  | Subtitle    |  | Subtitle / EQ               |
|  |  | Sleep       |  | Sleep / Timer               |
|  |  | Text        |  | Text / Goto                 |

