





































Original	Replacement
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Info	 Info
 Guia	 Guide
 ver Tv	 TV/R
 Favoritos	 Pre Ch
 Menu	 Menu

Original	Replacement
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Atrás	 Back
 Salir	 Exit
 abc/Borrar	 Options
 VOD/Videoclub	 Smart
 Familiar	 Subt
 Multimedia	 Media
 Vol+	 Vol +
 Vol-	 Vol -
 Prog+	 Ch +
 Prog-	 Ch -
 X/Zoom	 3D
 Rec	 Rec
 Play	 Play





Original		Replacement		Original	Replacement
	Pause		Pause		
	Stop		Stop		
	>>		>>		
	<<		<<		
	I<<		I<<		
	>>I		>>I		
	Red		Red		
	Green		Green		
	Yellow		Yellow		
	Blue		Blue		
	OK		Ok		
	Q..		Dual		

