



Original	Replacement	Original	Replacement
RCVR On	Power	RCVR Test / Menu	Menu
RCVR Standby	Shift + Power	RCVR Audio	Dual
RCVR Sleep	Sleep	RCVR Level	Media
RCVR Return	Back	RCVR Level Up	Smart
RCVR Setup	Options	RCVR I<<	I<<
RCVR Disc+	Ch +	RCVR Play	Play
RCVR Disc-	Ch -	RCVR >>I	>>I
RCVR Up	Up	RCVR <<	<<
RCVR Left	Left	RCVR Stop	Stop
RCVR Enter	Ok	RCVR >>	>>
RCVR Right	Right	RCVR Rec /	Rec
RCVR Down	Down	RCVR Pause / Play Rev.	Pause
RCVR Vol+	Vol +	Open / Close	Eject
RCVR Vol-	Vol -	RCVR Input Sel.	1
RCVR Muting	Mute	RCVR Input Sel.	2
RCVR CH Sel / Top Menu	Shift + Menu	RCVR Input Sel.	3
RCVR CH Sel / Top Menu	D. Menu	RCVR Input Sel.	4









































































Original		Replacement	
	RCVR Input Sel.		5
	RCVR Input Sel.		6
	RCVR Input Sel.		7
	RCVR Input Sel.		8
	RCVR Input Sel.		9
	RCVR Input Sel.		0
	RCVR Stereo	+	Shift + 1
	RCVR Direct	+	Shift + 2
	RCVR DSP ▶	+	Shift + 3
	RCVR SURR	+	Shift + 4
	RCVR THX	+	Shift + 5
	RCVR ◀ DSP	+	Shift + 6
	RCVR SP A	+	Shift + 7
	RCVR SP B	+	Shift + 8
	RCVR Re-EQ	+	Shift + 9
	RCVR Dimmer	+	Shift + 0
	RCVR Display		Info

Original		Replacement	
	RCVR Display		Guide
	RCVR Zone 2		Pre Ch
























































Original	Replacement	Original	Replacement
 ON	 Power	 Subtitle	 Subt
 STDBY	 Shift + Power	 I<<	 I<<
 Return	 Back	 Play	 Play
 Setup	 Options	 >>I	 >>I
 Disc+	 Ch +	 <<	 <<
 Disc-	 Ch -	 Stop	 Stop
 Up	 Up	 >>	 >>
 Left	 Left	 Random	 Text
 Enter	 Ok	 Pause	 Pause
 Right	 Right	 Open / Close	 Eject
 Down	 Down	 1	 1
 Vol+	 Vol +	 2	 2
 Vol-	 Vol -	 3	 3
 Muting	 Mute	 4	 4
 Top Menu	 D. Menu	 5	 5
 Menu	 Menu	 6	 6
 Angle	 Format	 7	 7














































Original	Replacement	Original	Replacement
	ON		Power
	STDBY		Shift + Power
	Disc+		Ch +
	Vol+		Vol +
	Vol-		Vol -
	Muting		Mute
	I<<		I<<
	Play		Play
	>>I		>>I
	<<		<<
	Stop		Stop
	>>		>>
	Random		Text
	Pause		Pause
	Open / Close		Eject
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	+10		Guide





Original	Replacement	Original	Replacement
	ON		Power
	STDBY		Shift + Power
	Vol+		Vol +
	Vol-		Vol -
	Muting		Mute
	I<<		I<<
	Play		Play
	>>I		>>I
	<<		<<
	Stop		Stop
	>>		>>
	Rec / Random		Text
	Rec / Random		Rec
	Pause		Pause
	Open / Close		Eject
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	+10		Guide
	Enter		Pre Ch
	Enter		Ok

