



Original		Replacement		Original		Replacement	
	Power		Power		9		9
	Menu		Menu		Vol+		Vol +
	Title		TV/R		Vol-		Vol -
	Home		Smart		Audio		Dual
	Zoom		Eject		Subtitle		Subt
	Rotate		Pre Ch		Angle		Red
	Thumbnails		Media		Up		Up
	Subtitle ♦		Options		Down		Down
	0		0		Right		Right
	1		1		Left		Left
	2		2		Play Enter		Ok
	3		3		Play All		Play
	4		4		Shuffle		Yellow
	5		5		Info		Info
	6		6		Back		Back
	7		7		I<<		I<<
	8		8		Pause/Step		Pause





	Original	Replacement	Original	Replacement
	>>I		>>I	
	<<		<<	
	Stop		Stop	
	>>		>>	
	Slow		Green	
	Mute		Mute	
	Repeat		Text	
	Repeat A-B		3D	
	Search	+	Shift + TV/R	
	Video Output		AV	

