



Original	Replacement
Power	Power
Open/Close	Eject
Status	AV
PIP	3D
Audio	Dual
Miracast	TV/R
Internet	Shift + Media
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0

Original	Replacement
#	Guide
*/Cancel	Format
<<	<<
Play	Play
>>	>>
I<<	I<<
Pause	Pause
>>I	>>I
Stop	Stop
[...] / CC	Subt
X/Exit	Exit
Pop-Up Menu/Top Menu	Menu
Netflix	Media
Home	Smart
Option	Options
Return	Back
Up	Up



