



Original	Replacement
Power Receiver	Power
DVD / Analog 6CH	Shift + 2
TV	Shift + 1
CD	Shift + 3
Tape / Monitor	Shift + 5
DVD Recorder	Shift + 7
VCR	Shift + 4
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
Volume+	Vol+

Original	Replacement
Disc / Direct Tuning	Smart / List
0	0
≥10 / -/--	Guide / EPG / -/--
Volume-	Vol-
I<< / <<	<< / Tune-
>> / >>I	>> / Tune+
Tuner / Band	Display / Media
Tuner / Band	Shift + 6
Muting	Mute / Dimmer
Up	Up
Menu / Play List	Menu / Home
Left	Left
Enter	OK
Right	Right
Down	Down
Subwoofer	Subtitle / EQ
Test / Setup	Setup / OPT /





Original	Replacement
CH- / -	CH PAGE - CH- / Page-
CH+ / +	CH PAGE + CH+ / Page+
MULTI REAR	TOP MENU D.MENU D.Menu / Top
LEVEL	ANGLE INFO Info / Angle
EFFECT	TITLE SOUND Sound / Title
STEREO/2CH MIX OFF	NETFLIX SEARCH Red / Netflix / Search
DOLBY PL IIx	APP REPEAT Green / APP / Repeat
DTS	YouTube REPEAT A-B Yellow / YouTube / Repeat
SFC	Prime Video RANDOM Blue / Prime Video / Random

Original	Replacement

