



Original	Replacement
	Power
	Input
	Menu
	Picture
	Text
	STTL
	Red
	Green
	Yellow
	Blue
	i
	X/Exit
	Netflix
	prime video
	Left
	Up
	Right

Original	Replacement
	Rakuten Tv
	OK
	Back
	Down
	Home
	Mute
	Option
	Guide
	List
	Vol+
	Smart Colors
	CH+
	Vol-
	CH-
	1
	2
	3





Original	Replacement	Original	Replacement
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	?/eHelp		Audio / Lang I/II
	0		0
	Last View		Fav / Marker / PC
	<<		<< / Tune-
	Play		Play / Slow
	>>		>> / Tune+
	Stop		Stop / Hold
	Pause		Pause / Step / Freeze
	Rec		Rec / Rec Mode
	My APP		TV/Radio /
	YouTube		Shift + Yellow / YouTube / Repeat
			APPS
			Shift + Green / APP /

