
































Original	Replacement	Original	Replacement
 Power	 Power	 Left	 Left
 1	 1	 OK	 OK
 2	 2	 Right	 Right
 3	 3	 I<<	 I<< / Preset-
 4	 4	 Down	 Down
 5	 5	 >>I	 >>I / Preset+
 6	 6	 Stop	 Stop / Hold
 7	 7	 Play	 Play / Slow
 8	 8	 Pause	 Pause / Step / Freeze
 9	 9	 Subtitle	 Subtitle / EQ
 Title/Return	 Back / Return	 Angle	 Info / Angle
 Title/Return	 Sound / Title	 Zoom	 Zoom / Size
 0	 0	 Audio	 Audio / Lang I/II
 Display	 Display / Media	 Repeat	 Green / APP / Repeat
 Disc Menu	 D.Menu / Top	 Repeat A-B	 Yellow / YouTube / Repeat
 Up	 Up	 Preview	 Smart / List
 System Menu	 Menu / Home	 Mute	 Mute / Dimmer

Original	Replacement	Original	Replacement
 Power	 Power	 Left	 Left
 1	 1	 OK	 OK
 2	 2	 Right	 Right
 3	 3	 I<<	 I<< / Preset-
 4	 4	 Down	 Down
 5	 5	 >>I	 >>I / Preset+
 6	 6	 Stop	 Stop / Hold
 7	 7	 Play	 Play / Slow
 8	 8	 Pause	 Pause / Step / Freeze
 9	 9	 Subtitle	 Subtitle / EQ
 Title/Return	 Back / Return	 Angle	 Info / Angle
 Title/Return	 Sound / Title	 Zoom	 Zoom / Size
 0	 0	 Audio	 Audio / Lang I/II
 Display	 Display / Media	 Repeat	 Green / APP / Repeat
 Disc Menu	 D.Menu / Top	 Repeat A-B	 Yellow / YouTube / Repeat
 Up	 Up	Preview	Smart / List
System Menu	Menu / Home	Mute	Mute / Dimmer

