









































Original	Replacement	Original	Replacement
	Power		Power
	I<<		I<<
	Play		Play
	Pause		Pause
	>>I		>>I
	Stop		Stop
	Menu		Menu
	Mode		Smart
	OK		Ok
	Album/Presets		Ch +
	Album/Presets		Ch -
	+		Vol +
	-		Vol -
	Mute		Mute
	Sound		Dual
	Info/RDS		Info
	Prog		D. Menu
	Sleep/Timer		Sleep
	Clock/Scan		AV





Original		Replacement		Original		Replacement	
	Power		Power		Sleep/Timer		Sleep
	I<<		I<<		Clock/Scan		AV
	Play		Play				
	Pause		Pause				
	>>I		>>I				
	Stop		Stop				
	Menu		Menu				
	Mode		Smart				
	OK		Ok				
	Album/Preset		Ch +				
	Album/Preset		Ch -				
	+		Vol +				
	-		Vol -				
	Mute		Mute				
	Sound		Dual				
	Info/RDS		Info				
	Prog		D. Menu				

