







































































| Original  | Replacement   |
|---|---|
|    |  Power                 |
|    |  D.Menu / Top          |
|    |  AV / Input / RDS      |
|    |  Setup / OPT /         |
|    |  Picture / Format      |
|    |  TV/Radio /            |
|    |  Exit / Cancel / Clear |
|    |  Guide / EPG / -/-     |
|    |  Display / Media       |
|   |  Smart / List         |
|  |  Up                  |
|  |  Left                |
|  |  OK                  |
|  |  Right               |
|  |  Down                |
|  |  Back / Return       |
|  |  Info / Angle        |

| Original  | Replacement   |
|---|---|
|    |  Menu / Home                 |
|    |  Red / Netflix / Search      |
|    |  Green / APP / Repeat        |
|    |  Yellow / YouTube / Repeat   |
|    |  Blue / Prime Video / Random |
|    |  Vol+                        |
|    |  Shift + Red / Netflix /     |
|    |  CH+ / Page+                 |
|    |  Vol-                        |
|   |  Mute / Dimmer              |
|  |  CH- / Page-               |
|  |  1                         |
|  |  2                         |
|  |  3                         |
|  |  4                         |
|  |  5                         |
|  |  6                         |



