


































































Original	Replacement
	 Power
	 Ambilight
	 Shift + Blue / Prime
	 Shift + Yellow / YouTube /
	 Shift + Red / Netflix /
	 D.Menu / Top
	 AV / Input / RDS
	 Exit / Cancel / Clear
	 Menu / Home
	 Up
	 Left
	 OK
	 Right
	 Down
	 Back / Return
	 Display / Media
	 Shift + Menu / Home

Original	Replacement
	 << / Tune-
	 Play / Slow
	 >> / Tune+
	 +/Options/Info
	 Pause / Step / Freeze
	 Stop / Hold
	 Red / Netflix / Search
	 Green / APP / Repeat
	 Yellow / YouTube / Repeat
	 Blue / Prime Video / Random
	 Vol+
	 Guide / EPG / -/-
	 CH+ / Page+
	 Vol-
	 Mute / Dimmer
	 CH- / Page-
	 1





	Original	Replacement		Original	Replacement
					
					
					
					
					
					
					
					
		Text			Text / Goto
		0			0
		*			Setup / OPT /

