







































































Original		Replacement		Original		Replacement	
	Standby/On		Power		Return		Back
	VCR Eject		Shift + Eject		Cancel		Exit
	DVD/VCR		Red		Title Menu/Top		Menu
	DVD		Eject		DVD Menu		D. Menu
	1		1		Setup		Options
	2		2		CH+		Ch +
	3		3		CH-		Ch -
	4		4		Up		Up
	5		5		Down		Down
	6		6		Right/TRK+		Right
	7		7		Left/TRK-		Left
	8		8		Enter		Ok
	9		9		Stop		Stop
	0		0		Play		Play
	Timer Rec		Guide		Pause/Still		Pause
	Input Select		AV		I<</Skip/Index-		I<<
	Show View		3D		<</Rew/Search		<<





Original	Replacement
>>/F.FWD/Search	>>
>>I/Skip/Index	>>I
One Touch	Text
CM Skip	Yellow
I> Slow	Blue
Rec	Rec
Rec Mode	+ Shift + Rec
Dubbing	Format
Audio/Audio	Dual
Display	Info
Zoom	+ Shift + 3D
Repeat A-B	+ Shift + Text
Zero Return	+ Shift + Back
Counter	Smart
Subtitle/ATR	Subt
Play Mode/Repeat	+ Shift + Play
Clock/Counter	+ Shift + Dual

Original	Replacement
Tv/Video	TV/R
Progressive	List

