











































































































































Original	Replacement	Original	Replacement
 Power	 Power	 P +	 Ch +
 1	 1	 P -	 Ch -
 2	 2	 Vol+	 Vol +
 3	 3	 Vol-	 Vol -
 4	 4	 Mute	 Mute
 5	 5	 Source Power	 AV
 6	 6	 Return	 Back
 7	 7	 Home	 Menu
 8	 8	 Up	 Up
 9	 9	 Down	 Down
 0	 0	 Right	 Right
 PC	 Pre Ch	 Left	 Left
 [i+]	 Info	 Enter	 Ok
 Split Screen	 Options	 Exit	 Exit
 Split Screen Swap	 3D	 EPG / DVD Top Menu / Guide	 Guide
 PIP Swap	 Shift + Back	 Red/Rec	 Red
 Tv/DTV	 TV/R	 Green/Pause	 Green







































































Original	Replacement	Original	Replacement
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	PC		Pre Ch
	Source Power		AV
	Mute		Mute
	Vol +		Vol +
	Vol -		Vol -
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Enter		Ok
	Menu		Menu
	DVD Top		D. Menu
	Return		Back
	Play		Play
	Stop		Stop
	Pause		Pause
	>>		>>
	<<		<<
	>>		>>
	<<		<<
	Input 1		Shift + 1
	Input 2		Shift + 2
	Input 3		Shift + 3











































Original	Replacement	Original	Replacement
 Power	 Power	 P +	 Ch +
 Source Power	 AV	 P -	 Ch -
 1	 1	 Menu	 Menu
 2	 2	 Exit	 Exit
 3	 3	 DVD Top Menu	 D. Menu
 4	 4	 Up	 Up
 5	 5	 Down	 Down
 6	 6	 Right	 Right
 7	 7	 Left	 Left
 8	 8	 Enter	 Ok
 9	 9	 Input 1	 Shift + 1
 0	 0	 Input 2	 Shift + 2
 PC	 Pre Ch	 Input 3	 Shift + 3
 [i+]	 Info	 Input 4	 Shift + 4
 Mute	 Mute	 Input 5	 Shift + 5
 Vol +	 Vol +		
 Vol -	 Vol -		





Original	Replacement	Original	Replacement
	Power		Mute
	Source Power		Mute
	AV		Play
	1		Play
	2		Stop
	3		Pause
	4		Rec
	5		Rec
	6		>>
	7		>>
	8		<<
	9		<<
	0		SHIFT + 1
	PC		SHIFT + 2
	Pre Ch		SHIFT + 3
	Vol +		SHIFT + 4
	Vol -		SHIFT + 5
	Ch +		
	Ch -		

