













































































































Original		Replacement		Original		Replacement	
	Power		Power		Mute		Mute
	3D		3D		Info		Info
	TV		TV/R		P+		Ch +
	1		1		P-		Ch -
	2		2		Option		Options
	3		3		Smart TV		Smart
	4		4		Guide		Guide
	5		5		Menu		Menu
	6		6		Up		Up
	7		7		Left		Left
	8		8		OK		Ok
	9		9		Right		Right
	0		0		Down		Down
	ECO		Shift + 3D		Back		Back
	Source		AV		Exit		Exit
	V+		Vol +		Zoom-		Shift + Down
	V-		Vol -		Zoom+		Shift + Up





Original		Replacement		Original		Replacement	
	@ / Δ		Media		<<		<<
	Sleep		Sleep		Rec		Rec
	Pre-CH		Pre Ch		>>		>>
	FAV		Shift + Pre Ch				
	List		List				
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				
	Lang		Dual				
	Subtitle		Subt				
	Text		Text				
	I<		I<<				
	Stop		Stop				
	Play / Pause		Play				
	Play / Pause		Pause				
	>I		>>I				

