









































Original	Replacement
 Power	 Power
 Mute	 Mute
 Red	 Red
 Green/Mouse	 Green
 Yellow	 Yellow
 Blue	 Blue
 <</Index	 <<
 >>/Hold	 >>
 I<</Size	 I<<
 >>I/Subpage	 >>I
 Play	 Play
 Pause	 Pause
 Stop	 Stop
 Nicam/A2	 Dual
 Subtitle	 Subt
 TXT	 Text
 Cancel	 Media

Original	Replacement
 Reveal	 3D
 EPG	 Guide
 Tv/Radio	 TV/R
 FAV	 Pre Ch
 Nothing 1	 D. Menu
 Sleep	 Sleep
 Disp	 Info
 Input	 AV
 Menu	 Menu
 Exit	 Exit
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 Vol+	 Vol +
 Vol-	 Vol -





Original	Replacement
 Home	 Smart
 CH.L	 List
 CH+	 Ch +
 CH-	 Ch -
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Nothing 2	 Eject
 Recall	 Back
 Picture	 Shift + Format

Original	Replacement
 Aspect	 Format
 Sound	 Shift + Dual

