







































































Original	Replacement	Original	Replacement
	Power		Power
	Sleep		Sleep
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	-/-- / 10+		Guide
	Recall		Back
	Source		AV
	-[ /]- / P.STD		Format
	-[ ]- / S.STD		Shift + Dual
	Menu / ATV		Menu
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Vol +		Vol +
	Vol -		Vol -
	Program +		Ch +
	Program -		Ch -
	Info		Info
	Setup / DVD /		Smart
	I/II		Dual
	[ /≡] / Text		Text
	Open / Close		Eject
	Play		Play



