



| Original  |       | Replacement   |              | Original  |              | Replacement   |         |
|---|-------|---|--------------|---|--------------|---|---------|
|    | Power |    | Power        |    | Menu         |    | Menu    |
|    | Mute  |    | Mute         |    | TV / AV      |    | AV      |
|    | 1     |    | 1            |    | Sleep        |    | Sleep   |
|    | 2     |    | 2            |    | Up / PR+     |    | Up      |
|    | 3     |    | 3            |    | Up / PR+     |    | Ch +    |
|    | 4     |    | 4            |    | Down / PR-   |    | Down    |
|    | 5     |    | 5            |    | Down / PR-   |    | Ch -    |
|    | 6     |    | 6            |    | Right / Vol+ |    | Right   |
|    | 7     |    | 7            |    | Right / Vol+ |    | Vol +   |
|    | 8     |    | 8            |    | Left / Vol-  |    | Left    |
|   | 9     |   | 9            |   | Left / Vol-  |   | Vol -   |
|  | 0     |  | 0            |  | OK           |  | Ok      |
|  | *     |  | Guide        |  | Text / Mix   |  | Text    |
|  | *     |  | Pre Ch       |  | Q.View       |  | Options |
|  | PSM   |  | Format       |  | List         |  | List    |
|  | SSM   |  | Shift + Dual |  | Red          |  | Red     |
|  | I/II  |  | Dual         |  | Green        |  | Green   |





| Original  |            | Replacement   |               | Original | Replacement |
|---|------------|---|---------------|----------|-------------|
|    | Yellow     |    | Yellow        |          |             |
|    | Blue       |    | Blue          |          |             |
|    | Update     |    | Subt          |          |             |
|    | Time       |    | Eject         |          |             |
|    | Reveal     |    | TV/R          |          |             |
|    | Hold       |    | Stop          |          |             |
|    | PIP/*      |    | 3D            |          |             |
|    | ARC        |    | Smart         |          |             |
|    | TV / PC    |    | Back          |          |             |
|    | Position/* |    | Media         |          |             |
|   | Swap/*     |   | Shift + Media |          |             |
|  | Input/*    |  | Shift + AV    |          |             |
|  | Mode/*     |  | Shift + 3D    |          |             |
|  | PR+/*      |  | Shift + Ch +  |          |             |
|  | PR-/*      |  | Shift + Ch -  |          |             |
|   |            |   |               |          |             |
|   |            |   |               |          |             |

