



































































Original		Replacement		Original		Replacement	
	Standby		Power		Canc		Exit / Cancel / Clear
	Equalizzatore		Shift + Sound / Title		0/10		0
	Surround		Shift + Eject / Surround		10+		Guide / EPG / -/-
	Eject		Eject / Surround		Titolo		Sound / Title
	Audio		Audio / Lang I/II		Up		Up
	1		1		Menu		Menu / Home
	2		2		Left		Left
	3		3		OK		OK
	Angle		Info / Angle		Right		Right
	4		4		Programm		TV/Radio /
	5		5		Down		Down
	6		6		Display		Display / Media
	Sottotitoli		Subtitle / EQ		PAL/NTSC		D.Menu / Top
	7		7		Setup		Setup / OPT /
	8		8		Digest		Shift + D.Menu / Top Menu
	9		9		Vol+		Vol+
	Ricerca		Red / Netflix / Search		Mute		Mute / Dimmer





	Original	Replacement	Original	Replacement
		Mark		Fav / Marker / PC
		Zoom		Zoom / Size
		Vol-		Vol-
		A-B		Yellow / YouTube / Repeat
		Ripeti		Back / Return
		Slow		Shift + Play /
		<</F.RWD		<< / Tune-
		F.FWD/>>		>> / Tune+
		l<< / Skip-		l<< / Preset-
		>>l / Skip+		>>l / Preset+
		Stop		Stop / Hold
		Pause/Step		Pause / Step / Freeze
		Play		Play / Slow

