





















| Original  |            | Replacement   |               | Original  |                | Replacement   |                |
|---|------------|---|---------------|---|----------------|---|----------------|
|    | Power      |    | Power         |    | Aspect         |    | Format         |
|    | Eject/Auto |    | Eject         |    | Audio          |    | Dual           |
|    | Mute       |    | Mute          |    | CH+            |    | Ch +           |
|    | 1          |    | 1             |    | CH-            |    | Ch -           |
|    | 2          |    | 2             |    | Display        |    | Info           |
|    | 3          |    | 3             |    | Up             |    | Up             |
|    | 4          |    | 4             |    | Right          |    | Right          |
|    | 5          |    | 5             |    | Down           |    | Down           |
|    | 6          |    | 6             |    | Left           |    | Left           |
|    | 7          |    | 7             |    | OK             |    | Ok             |
|   | 8          |   | 8             |   | LCD Menu       |   | Menu           |
|  | 9          |  | 9             |  | DVD Setup/Exit |  | Exit           |
|  | 0          |  | 0             |  | DVD Setup/Exit |  | Options        |
|  | -/--       |  | Shift + Guide |  | Input          |  | AV             |
|  | Recall     |  | Pre Ch        |  | P.Mode         |  | Shift + Format |
|  | Vol+       |  | Vol +         |  | S.Mode         |  | Shift + Dual   |
|  | Vol-       |  | Vol -         |  | Sleep          |  | Sleep          |





| Original   | Replacement  |
|--|--|
|  FAV            |  Shift + Pre Ch |
|  FAV-           |  Shift + Ch -   |
|  FAV+           |  Shift + Ch +   |
|  EPG            |  Guide          |
|  Angle/Text     |  Text           |
|  Zoom/Hold      |  Shift + Eject  |
|  Tv/Radio       |  TV/R           |
|  Goto/Subpage   |  3D             |
|  D.Disp/Reveal  |  List           |
|  Subtitle       |  Subt           |
|  Title/Size    |  Smart         |
|  D.Menu/Index |  D. Menu      |
|  I>/Media     |  Media        |
|  Play/Pause   |  Play         |
|  <<           |  <<           |
|  Play/Pause   |  Pause        |
|  >>           |  >>           |

| Original  | Replacement  |
|---|--|
|  Rec           |  Rec    |
|  Stop          |  Stop   |
|  I<<           |  I<<    |
|  >>I           |  >>I    |
|  Red/Prog      |  Red    |
|  Green/Intro   |  Green  |
|  Yellow/Repeat |  Yellow |
|  Blue/A-B      |  Blue   |

