



Original	Replacement	Original	Replacement
	Power		Power
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Jump		Back
	-/--		Shift + Guide
	S.Mode		Shift + Dual
	I-II		Dual
	P.Mode		Format
	Guide		Guide
	Exit		Exit
	Up		Up
	Left		Left
	OK		Ok
	Right		Right
	Down		Down
	Input		AV
	Menu		Menu
	Fav. CH		Pre Ch
	Vol. +		Vol +
	Vol.-		Vol -
	CH. +		Ch +
	CH.-		Ch -
	Rec		Rec
	DTV / Radio		TV/R
	Sleep		Sleep





Original		Replacement		Original		Replacement	
	Subtitle		Subt		>>		>>
	P.Size		Eject		<<		<<
	Subpage	 + 	Shift + Subt		>>		>>
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				
	[≡i]		Smart				
	[≡?]		Media				
	[≡↓]		3D				
	[≡□]	 + 	Shift + Stop				
	[≡] / [/≡]		Text				
	Stop		Stop				
	Play/Pause / Timeshift		Play				
	Play/Pause / Timeshift		Pause				
	Info		Info				
	<<		<<				

