







































































| Original | Replacement | Original | Replacement |
|---|-------------|---|---------------|
|  | Power |  | Power |
|  | Source |  | AV |
|  | Subt. |  | Subt |
|  | 1 |  | 1 |
|  | 2 |  | 2 |
|  | 3 |  | 3 |
|  | 4 |  | 4 |
|  | 5 |  | 5 |
|  | 6 |  | 6 |
|  | 7 |  | 7 |
|  | 8 |  | 8 |
|  | 9 |  | 9 |
|  | 0 |  | 0 |
|  | -/-- |  | Shift + Guide |
|  | PRE-CH |  | Pre Ch |
|  | TTX/MIX |  | Text |
|  | HDMI |  | Smart |
|  | DTV |  | TV/R |
|  | Vol+ |  | Vol + |
|  | Vol- |  | Vol - |
|  | Mute |  | Mute |
|  | PR+ |  | Ch + |
|  | PR- |  | Ch - |
|  | CH.List |  | List |
|  | Menu |  | Menu |
|  | Media.P |  | Media |
|  | Guide |  | Guide |
|  | Tools |  | Options |
|  | Info |  | Info |
|  | Up |  | Up |
|  | Down |  | Down |
|  | Right |  | Right |
|  | Left |  | Left |
|  | Enter |  | Ok |



