







































































Original		Replacement		Original		Replacement	
	Power		Power		Vol-		Vol-
	Source		AV / Input / RDS		CH List		Shift + Smart / List
	1		1		CH List		Display / Media
	2		2		P-		CH- / Page-
	3		3		Menu		Menu / Home
	4		4		Smart Hub		Smart / List
	5		5		Guide		Guide / EPG / -/-
	6		6		Tools		Setup / OPT /
	7		7		Up		Up
	8		8		Info		Info / Angle
	9		9		Left		Left
	TTX/MIX		Text / Goto		Enter		OK
	0		0		Right		Right
	PRE-CH		Back / Return		Return		Shift + Back / Return
	Vol+		Vol+		Down		Down
	Mute		Mute / Dimmer		Exit		Exit / Cancel / Clear
	P+		CH+ / Page+		Red/A		Red / Netflix / Search





	Original	Replacement	Original	Replacement
		Green / APP / Repeat		
		Yellow / YouTube / Repeat		
		Blue / Prime Video / Random		
		D.Menu / Top		
		TV/Radio /		
		Subtitle / EQ		
		Audio / Lang I/II		
		Stop / Hold		
		<< / Tune-		
		I<< / Preset-		
		Play / Slow		
		Pause / Step / Freeze		
		>> / Tune+		
		>>I / Preset+		

