

































































































Original	Replacement	Original	Replacement
 Power	 Power	 Guide	 Guide
 Source	 AV	 Tools	 Options
 1	 1	 Smart Hub	 Smart
 2	 2	 Info	 Info
 3	 3	 Return	 Back
 4	 4	 Exit	 Exit
 5	 5	 Enter	 Ok
 6	 6	 Up	 Up
 7	 7	 Down	 Down
 8	 8	 Right	 Right
 9	 9	 Left	 Left
 0	 0	 Red	 Red
 TTX/MIX	 Text	 Green	 Green
 PRE-CH	 Pre Ch	 Yellow	 Yellow
 Mute	 Mute	 Blue	 Blue
 CH List	 List	 Social Tv	 Media
 Menu	 Menu	 3D	 3D





	Original	Replacement		Original	Replacement
	P.Size	 Format			
	AD/Subt.	 Subt			
	Search	 TV/R			
	E-Manual	 D. Menu			
	Play	 Play			
	Rec	 Rec			
	Stop	 Stop			
	Pause	 Pause			
	<</ <<	 <<			
	>>/>>	 >>			
	Vol+	 Vol +			
	Vol-	 Vol -			
	P+	 Ch +			
	P-	 Ch -			

