






















































	Original	Replacement		Original	Replacement
	Power		Power		Angle/TTX
	Goto		Back		Audio
	Mute		Mute		PBC/Scan
	Source		AV		Title
	1		1		Stop
	2		2		Play
	3		3		Pause
	4		4		Mode
	5		5		Setup
	6		6		Up
	7		7		Down
	8		8		Right
	9		9		Left
	0		0		Enter
	10+		Pre Ch		Yellow/Zoom
	Step		Smart		Red/Menu
	Subtitle		Subt		Green
					Text
					Dual
					Media
					3D
					Play
					Format
					Options
					Up
					Down
					Right
					Left
					Ok
					Yellow
					Red
					Green





Original	Replacement
	Blue
	I<<
	>>I
	TV/R
	+ Shift + Text
	Guide
	Info
	<<
	>>

Original	Replacement

