







































































| Original | Replacement | Original | Replacement |
|---|--|--|---|
|  Power |  Power |  P+ |  Ch + |
|  1 |  1 |  P- |  Ch - |
|  2 |  2 |  Menu |  Menu |
|  3 |  3 |  EPG |  Guide |
|  4 |  4 |  [≡] |  Text |
|  5 |  5 |  End |  Exit |
|  6 |  6 |  Back |  Back |
|  7 |  7 |  Home |  Smart |
|  8 |  8 |  3D |  3D |
|  9 |  9 |  Netflix |  Media |
|  0 |  0 |  ▼/O)/I/II+II |  Dual |
|  Source |  AV |  [<>] |  Format |
|  Last View |  Pre Ch |  APP |  Shift + Media |
|  AV Mode |  Shift + AV |  Eco |  Shift + 3D |
|  Mute |  Mute |  [...] |  Subt |
|  Vol+ |  Vol + |  [≡?] |  Options |
|  Vol- |  Vol - |  [≡o] |  List |





| Original | Replacement |
|---|--|
|  [≡+] |  Sleep |
|  Red |  Red |
|  Green |  Green |
|  Yellow |  Yellow |
|  Blue |  Blue |
|  OK |  Ok |
|  Up |  Up |
|  Down |  Down |
|  Right |  Right |
|  Left |  Left |
|  Radio |  TV/R |
|  SAT |  Eject |
|  DTV |  Shift + Pre Ch |
|  ATV |  Shift + Guide |
|  P.Info |  Shift + Info |
|  [i+] |  Info |
|  Control |  D. Menu |

| Original | Replacement |
|---|---|
|  Power Ext |  Shift + Power |
|  Rec |  Rec |
|  Play |  Play |
|  << |  << |
|  >> |  >> |
|  Stop |  Stop |
|  I<< |  I<< |
|  >>I |  >>I |
|  Pause |  Pause |
|  Rec Stop |  Shift + Stop |
|  ← |  Shift + Left |
|  → |  Shift + Right |

