





Original	Replacement
 Power	 Power
 Text	 Text
 [≡?]	 Shift + D. Menu
 Subtitles	 Subt
 [≡]	 Shift + Format
 [≡o]	 3D
 Size	 Eject
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0

Original	Replacement
 Recall	 Pre Ch
 Source	 AV
 DTV	 TV/R
 EPG	 Guide
 ESG	 Smart
 Radio	 Media
 Audio I / II	 Dual
 Mute	 Mute
 Vol +	 Vol +
 Vol -	 Vol -
 P +	 Ch +
 P -	 Ch -
 AV Mode	 Shift + AV
 Surround	 Shift + Dual
 DTV Menu	 Options
 DTV Menu	 D. Menu
 List	 List





Original		Replacement		Original	Replacement
	Info		Info		
	Menu		Menu		
	Up		Up		
	Down		Down		
	Right		Right		
	Left		Left		
	OK		Ok		
	End		Exit		
	Return		Back		
	Red		Red		
	Green		Green		
	Yellow		Yellow		
	Blue		Blue		
	truD		Play		
	Sleep		Sleep		
	Video Format		Format		
	OPC		Pause		

