



Original	Replacement
On/Stand-by	Power
MP3 Display	Media
Clock	List
Sleep	Sleep
Timer	AV
Surround	Dual
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
+10	Guide

Original	Replacement
<</Tuning	<<
>>/Tuning Up	>>
I<</Preset	I<<
>>I/Preset Up	>>I
Pause	Pause
Play	Play
Stop	Stop
Rec Pause	Rec
Vol+	Vol +
Vol-	Vol -
PTY-TI	Options
ASPM	Subt
Display	Info
Bass+	Ch +
Bass-	Ch -
Treble+	Right
Treble-	Left





Original	Replacement
MEMORY Memory	SEARCH TV/R TV/R
CLEAR Clear	CLEAR EXIT
REPEAT Repeat	REPEAT TEXT
RANDOM Random	HOME SMART
C D CD	D Blue
TUNER(BAND) Tuner(Band)	B Green
TAPE Tape	C Yellow
VIDEO/AUX Video/AUX	A Red

Original	Replacement

