














































Original	Replacement	Original	Replacement
	Power		Power
	TV/VTR		TV/Radio /
	Eject		Eject / Surround
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	-/--		Guide / EPG / -/--
	Prog+		CH+ / Page+
	Prog-		CH- / Page-
	Vol+		Vol+
	Vol-		Vol-
	Play		Play / Slow
	Stop		Stop / Hold
	Pause		Pause / Step / Freeze
	Search >>		>> / Tune+
	Index Search >>		>>  / Preset+
	I<< Index Search		I<< / Preset-
	X2		Smart / List
	<< Search		<< / Tune-
	Skip		Exit / Cancel / Clear
	Wheel >/Frame		Shift + >>  / Preset+
	Up		Up
	< Wheel/<		Shift + I<< / Preset-
	Down		Down
	Right		Right
	Left		Left
	Menu		Menu / Home





**Original**

**Replacement**

	Execute		Blue / Prime Video / Random
	Input Select		AV / Input / RDS
	Audio Monitor		Audio / Lang I/II
	Time Clear		Shift + Exit / Cancel / Clear
	Auto/Manu		Setup / OPT /
	Tracking Normal/Slow ▼		Shift + CH- /
	Display		Display / Media
	Tracking Normal/Slow ▲		Shift + CH+ /
	Counter Reset		Back / Return
	Rec		Rec / Rec Mode
	Tape Speed SP/LP		Zoom / Size
	Still Adjust I> Slow+		Shift + >> /
	Still Adjust I> Slow-		Shift + << /
	Quick Timer		Sleep / Timer
	Timer Check		Shift + Sleep / Timer
	Showview		Picture / Format
	VPS/PDC		D.Menu / Top

**Original**

**Replacement**

	Once		Red / Netflix / Search
	Daily		Green / APP / Repeat
	Weekly		Yellow / YouTube / Repeat





Original	Replacement	Original	Replacement
	Power		Power
	Display		Display / Media
	TV/VTR		TV/Radio /
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	-/--		Guide / EPG / -/--
	Vol+		Vol+
	Vol-		Vol-
	Prog+		CH+ / Page+
	Prog-		CH- / Page-
	Audio Monitor		Audio / Lang I/II
	Red		Red / Netflix / Search
	Green		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat
	Blue		Blue / Prime Video / Random
	[≡]		Text / Goto
	[ ]		Smart / List

