







































| Original | Replacement |
|--|--|
|  Operate |  Power |
|  Sleep |  Sleep |
|  Function |  Menu |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  0/10 |  0 |
|  >10 |  Guide |
|  Mode |  Format |
|  Vol+ |  Vol + |
|  Vol- |  Vol - |

| Original | Replacement |
|--|---|
|  Band |  TV/R |
|  Tune+ |  >> |
|  Tune- |  << |
|  Play |  Play |
|  Pause |  Pause |
|  Stop |  Stop |
|  I<< |  I<< |
|  >>I |  >>I |
|  Mega Xpand |  Options |
|  Mega Bass |  Subt |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

