







































































Original	Replacement	Original	Replacement
	Power		Power
	Mute		Mute
	[]		Smart
	[≡]		Text
	Input		AV
	Output		Media
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	-/--		Guide
	C		Pre Ch
	[*]		TV/R
	[↔*]		Subt
	[↑*]		Sleep
	[↑]		Options
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	[≡+]		3D
	[> <]		List
	Vol+		Vol +
	Vol-		Vol -
	Prog+		Ch +
	Prog-		Ch -
	[+]		Info
	SAT		Back























Original	Replacement	Original	Replacement
	Picture		Format
	[+]		Eject
	♪		Dual
	Up/+		Up
	Down/-		Down
	←		Left
	Menu		Menu
	OK		Ok
	Power MDP		Shift + Power
>> MDT button icon"/>	>> MDT	>> button icon"/>	>>
	Play MDT		Play
<< MDT button icon"/>	<< MDT	<< button icon"/>	<<
	Stop MDT		Stop
	Pause MDT		Pause
	Prog+ MDT		Shift + Ch +
	Prog- MDT		Shift + Ch -

Original	Replacement	Original	Replacement





	Original	Replacement	Original	Replacement
	Power			
	Prog+			
	Prog-			
	>>			
	Play			
	<<			
	Stop			
	Pause			
	Rec			





Original	Replacement	Original	Replacement
	Power		Power
	Prog+		Ch +
	Prog-		Ch -
	>>		>>
	Play		Play
	<<		<<
	Stop		Stop
	Pause		Pause
	Rec		Rec





	Original	Replacement	Original	Replacement
	Power		Power	
	Prog+		Ch +	
	Prog-		Ch -	
	>>		>>	
	Play		Play	
	<<		<<	
	Stop		Stop	
	Pause		Pause	
	Rec		Rec	

