








































































Original	Replacement	Original	Replacement
	Power		Power
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	-/--	 + 	Shift + Guide
	Recall		Pre Ch
	Vol+		Vol +
	Vol-		Vol -
	Nicam		Smart
	DVB Menu		Media
	CH+		Ch +
	CH-		Ch -
	Menu		Menu
	Back		Back
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	AV/Tv		AV
	EPG		Guide
	SUBT		Subt
	i/Info		Info
	[≡]/Text		Text
	[≡+]/Hold		Dual
	[▼]/PGDN		<<





	Original	Replacement	Original	Replacement
	[▲]PGUP	 >>		
	[≡i]/Index	 Exit		
	[≡◆]/Size	 Format		
	[≡?]/Reveal	 TV/R		
	[≡o]/Subpage	 D. Menu		
	Red	 Red		
	Green	 Green		
	Yellow	 Yellow		
	Cyan	 Blue		
	Sleep	 Sleep		
	FAV	 +  Shift + Pre Ch		
	Last	 Eject		
	P-Mode	 3D		

