
































Original	Replacement	Original	Replacement
 Power	 Power	 PIP	 3D
 Mute	 Mute	 Lang	 Dual
 1	 1	 Prog+	 Ch +
 2	 2	 Prog-	 Ch -
 3	 3	 Up	 Up
 4	 4	 Left	 Left
 5	 5	 Menu	 Menu
 6	 6	 Menu	 Ok
 7	 7	 Right	 Right
 8	 8	 Down	 Down
 9	 9	 Text	 Text
 0	 0	 Q.View	 List
 -/--	 Guide	 Index	 Info
 Input	 AV	 Hold	 Stop
 Vol +	 Vol +	 Sub Page	 Subt
 Vol -	 Vol -	 Reveal	 Media
 Sleep	 Sleep	 Red / Sound	 Red



