




































| Original | Replacement | Original | Replacement |
|-------------|--|------------|--|
| On/Off |  Power | OK Enter |  Ok |
| Mute |  Mute | Menu Right |  Right |
| Update |  Smart | Menu Off |  Exit |
| Reveal |  Media | Menu Down |  Down |
| Txt Stop |  Stop | Back |  Back |
| Info |  +  Shift + Info | Volume+ |  Vol + |
| Subt.List |  Subt | Chan.Up |  Ch + |
| Sleep Timer |  Sleep | Volume- |  Vol - |
| Return TV |  TV/R | Chan.Down |  Ch - |
| Menu video |  D. Menu | 1 |  1 |
| Text |  Text | Menu audio |  Dual |
| Txt Expand |  Eject | 2 |  2 |
| TV/AV |  AV | 3 |  3 |
| Menu |  Menu | 4 |  4 |
| Menu Up |  Up | 5 |  5 |
| Display |  Info | 6 |  6 |
| Menu Left |  Left | 7 |  7 |



| Original | Replacement | Original | Replacement |
|---------------|--|----------|-------------|
| 8 |  8 | | |
| 9 |  9 | | |
| Guide -/-- 1. |  Guide | | |
| 0/10 |  0 | | |
| 2.Fav P/C 2. |  Pre Ch | | |
| Red |  Red | | |
| Green |  Green | | |
| Yellow |  Yellow | | |
| Blue |  Blue | | |
| AV 2 |  +  Shift + AV | | |
| Color+ P.Std |  Format | | |
| Disp |  3D | | |
| Bright+ Mode |  >> | | |
| Color- S.Std |  +  Shift + Dual | | |
| Bright- Sys |  << | | |
| | | | |
| | | | |

