



































| Original | Replacement | Original | Replacement |
|-------------|---|---------------|--|
| On/Off |  Power | Volume+ |  Vol + |
| Mute |  Mute | Chan.Up |  Ch + |
| Update |  Smart | Volume- |  Vol - |
| Info |  Info | Menu audio |  Dual |
| Subt.List |  Subt | Chan.Down |  Ch - |
| Sleep Timer |  Sleep | 1 |  1 |
| Return TV |  TV/R | 2 |  2 |
| Menu video |  D. Menu | 3 |  3 |
| Text |  Text | 4 |  4 |
| TV/AV |  AV | 5 |  5 |
| Menu |  Menu | 6 |  6 |
| Menu Up |  Up | 7 |  7 |
| Menu Left |  Left | 8 |  8 |
| OK Enter |  Ok | 9 |  9 |
| Menu Right |  Right | Guide -/-- 1. |  Guide |
| Menu Off |  Exit | 0/10 |  0 |
| Menu Down |  Down | 2.Fav P/C 2. |  Pre Ch |



