












Original	Replacement	Original	Replacement
 Power	 Power	 Right	 Right
 LIB	 List	 Left	 Left
 Mute	 Mute	 PR+	 Ch +
 <<	 <<	 PR-	 Ch -
 Play	 Play	 VOL+	 Vol +
 >>	 >>	 VOL-	 Vol -
 Rec	 Rec	 Red	 Red
 Pause	 Pause	 Green	 Green
 Stop	 Stop	 Yellow	 Yellow
 Timers	 Sleep	 Blue	 Blue
 Guide	 Guide	 1	 1
 Back	 Back	 2	 2
 Text	 Text	 3	 3
 Info	 Info	 4	 4
 OK	 Ok	 5	 5
 Up	 Up	 6	 6
 Down	 Down	 7	 7





Original		Replacement		Original		Replacement	
	8		8				
	9		9				
	0		0				
	AUX		AV				
	P<P		Pre Ch				
	Menu		Menu				
	SUBT.		Subt				
	FAV.	+	Shift + Pre Ch				
	PIP-		Media				
	PIP		3D				
	WIDE		Format				
	PIP+		Smart				
	Swap		Options				

