







































































Original	Replacement	Original	Replacement
 Power	 Power	 World	 Media
 Source	 AV	 Vol+	 Vol +
 1	 1	 Vol-	 Vol -
 2	 2	 PR+	 Ch +
 3	 3	 PR-	 Ch -
 4	 4	 OK	 Ok
 5	 5	 Up	 Up
 6	 6	 Down	 Down
 7	 7	 Right	 Right
 8	 8	 Left	 Left
 9	 9	 Back	 Back
 0	 0	 Exit	 Exit
 TV	 TV/R	 i	 Info
 Mute	 Mute	 Guide	 Guide
 Recall	 Pre Ch	 /Music/Photo/Movi	 Dual
 Menu	 Menu	 [=]/Text	 Text
 Q.Menu	 D. Menu	 */o	 Format





Original		Replacement		Original		Replacement	
	* / 0 ..		3D				
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				
	Lang		List				
	[≡] ..		Subt				
	[-o-]		Shift + 3D				
	Rec		Rec				
	Play		Play				
	Pause		Pause				
	Stop		Stop				
	>>		>>				
	<<		<<				

