















































































Original	Replacement	Original	Replacement
	Power		Power
	Mute		Mute
	More		Smart
	Code		Media
	Code		Shift + Media
	Sleep		Sleep
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Zoom		Eject
	OPT		Options
	Red / <<		Red
	Green / Stop		Green
	Yellow /		Yellow
	Blue / >>		Blue
	Red / <<		<<
	Green / Stop		Stop
	Yellow /		Play
	Yellow /		Pause
	Blue / <<		>>
	Up		Up
	Left		Left
	OK		Ok
	Right		Right
	Down		Down
	TV/Radio		TV/R
	Rec		Rec









































Original		Replacement		Original		Replacement	
	Back		Back				
	Info		Info				
	Prog-		Ch -				
	Prog+		Ch +				
	Vol-		Vol -				
	Vol+		Vol +				
	TXT		Text				
	Still	 + 	Shift + Pause				
	Sound		Dual				
	PIP		Format				
	Menu		Menu				
	HDMI		AV				





Original	Replacement	Original	Replacement
PWR On/Off	 Power	OK Enter	 Ok
Mute	 Mute	Menu Right	 Right
Epg	 +  Shift + Guide	Exit	 Exit
Opt?	 Options	Menu Down	 Down
Subt.List	 Subt	Back	 Back
App	 Media	Audio	 Dual
Info	 +  Shift + Info	Volume+	 Vol +
Sleep Timer	 Sleep	CH/Page+	 Ch +
TV	 TV/R	Volume-	 Vol -
Video	 D. Menu	CH/Page-	 Ch -
Text	 Text	1. ?	 1
Zoom	 Eject	2abc	 2
TV/SAT	 AV	3def	 3
Menu	 Menu	4ghi	 4
Menu Up	 Up	5jkl	 5
Display	 Info	6mno	 6
Menu Left	 Left	7pqrm	 7




























































Original	Replacement	Original	Replacement
8tuv	8	Lang./Rewind	<<
9wxyz	9	LNB F.Forward	>>
Guide Pilote	Guide		
0/10	0		
FAV Pref.	Pre Ch		
Red	Red		
Green	Green		
Dev	List		
Home Cinema	Smart		
West	I<<		
Yellow	Yellow		
Freeze	Stop		
Blue	Blue		
On/Off	+  Shift + Power		
SAT Sky	+  Shift + AV		
H/V Play	Play		
East	>>I		

































Original	Replacement	Original	Replacement
PWR On/Off	 Power	Menu Right	 Right
Mute	 Mute	Exit	 Exit
Epg	 +  Shift + Guide	Menu Down	 Down
Sleep Timer	 Sleep	Back	 Back
Opt?	 Options	Audio	 Dual
App	 Media	Volume+	 Vol +
Info	 +  Shift + Info	CH/Page+	 Ch +
TV	 TV/R	Volume-	 Vol -
Video	 D. Menu	CH/Page-	 Ch -
Text	 Text	1. ?	 1
Zoom	 Eject	2abc	 2
TV/SAT	 AV	3def	 3
Menu	 Menu	4ghi	 4
Menu Up	 Up	5jkl	 5
Display	 Info	6mno	 6
Menu Left	 Left	7pqrm	 7
OK Enter	 Ok	8tuv	 8

Menu Right	 Right
Exit	 Exit
Menu Down	 Down
Back	 Back
Audio	 Dual
Volume+	 Vol +
CH/Page+	 Ch +
Volume-	 Vol -
CH/Page-	 Ch -
1. ?	 1
2abc	 2
3def	 3
4ghi	 4
5jkl	 5
6mno	 6
7pqrm	 7
8tuv	 8





Original	Replacement	Original	Replacement
9wxyz	 9	East	 >>
Guide Pilote	 Guide	Lang./Rewind	 <<
0/10	 0	H/V Play	 Play
FAV Pref.	 Pre Ch	LNB F.Forward	 >>
Freeze	 Stop		
Scan/Setup	 +  Shift + Options		
Red	 Red		
Auth./DISEQC	 List		
Green	 Green		
Radio	 +  Shift + TV/R		
Yellow	 Yellow		
Blue	 Blue		
Home Cinema	 Smart		
Alt/16:9	 Format		
SAT Sky	 +  Shift + AV		
Dec/Pause	 Pause		
	 +  Shift + Exit		

Original	Replacement	Original	Replacement
9wxyz	 9	East	 >>
Guide Pilote	 Guide	Lang./Rewind	 <<
0/10	 0	H/V Play	 Play
FAV Pref.	 Pre Ch	LNB F.Forward	 >>
Freeze	 Stop		
Scan/Setup	 +  Shift + Options		
Red	 Red		
Auth./DISEQC	 List		
Green	 Green		
Radio	 +  Shift + TV/R		
Yellow	 Yellow		
Blue	 Blue		
Home Cinema	 Smart		
Alt/16:9	 Format		
SAT Sky	 +  Shift + AV		
Dec/Pause	 Pause		
	 +  Shift + Exit		

