



| Original | Replacement | Original | Replacement |
|--|--|--|--|
|  Power |  Power |  Left |  Left |
|  Mute |  Mute |  OK |  Ok |
|  1 |  1 |  Right |  Right |
|  2 |  2 |  Down |  Down |
|  3 |  3 |  EPG |  Guide |
|  4 |  4 |  TV/Radio |  TV/R |
|  5 |  5 |  Red |  Red |
|  6 |  6 |  Green |  Green |
|  7 |  7 |  Yellow |  Yellow |
|  8 |  8 |  Blue |  Blue |
|  9 |  9 |  Rec |  Rec |
|  0 |  0 |  Fav |  Pre Ch |
|  Info |  Info |  Stop |  Stop |
|  Back |  Back |  Media |  Media |
|  Menu |  Menu |  I<< |  I<< |
|  Exit |  Exit |  >>I |  >>I |
|  Up |  Up |  >> |  >> |





| Original | | Replacement | | Original | | Replacement | |
|---|----------|---|-------|----------|--|-------------|--|
|  | << |  | << | | | | |
|  | Play |  | Play | | | | |
|  | Pause |  | Pause | | | | |
|  | TTX |  | Text | | | | |
|  | Audio |  | Dual | | | | |
|  | Subtitle |  | Subt | | | | |
|  | USB |  | Smart | | | | |
|  | Timer |  | AV | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |

