




















| Original | Replacement                 |
|----------|-----------------------------|
|          | Power                       |
|          | Shift + 3                   |
|          | Shift + 5                   |
|          | Shift + 6                   |
|          | Shift + 1                   |
|          | Shift + 2                   |
|          | Shift + 4                   |
|          | Red / Netflix / Search      |
|          | Green / APP / Repeat        |
|          | Yellow / YouTube / Repeat   |
|          | Blue / Prime Video / Random |
|          | TV/Radio /                  |
|          | Exit / Cancel / Clear       |
|          | Menu / Home                 |
|          | Up                          |
|          | Down                        |
|          | Right                       |


















| Original | Replacement   |
|----------|---------------|
|          | Left          |
|          | OK            |
|          | Vol+          |
|          | Vol-          |
|          | CH+ / Page+   |
|          | CH- / Page-   |
|          | Mute / Dimmer |
|          | 1             |
|          | 2             |
|          | 3             |
|          | 4             |
|          | 5             |
|          | 6             |
|          | 7             |
|          | 8             |
|          | 9             |
|          | 0             |
























| Original | Replacement                                                                         | Original         | Replacement |
|----------|-------------------------------------------------------------------------------------|------------------|-------------|
| Power    |    | Power            |             |
| 1        |    | 1                |             |
| 2        |    | 2                |             |
| 3        |    | 3                |             |
| 4        |    | 4                |             |
| 5        |    | 5                |             |
| 6        |    | 6                |             |
| 7        |    | 7                |             |
| 8        |    | 8                |             |
| 9        |   | 9                |             |
| 0/--     |  | 0                |             |
| AV       |  | AV / Input / RDS |             |
| Mute     |  | Mute / Dimmer    |             |
| Vol+     |  | Vol+             |             |
| Vol-     |  | Vol-             |             |
| PR+      |  | CH+ / Page+      |             |
| PR-      |  | CH- / Page-      |             |


















| Original    | Replacement                                                                           | Original                    | Replacement |
|-------------|---------------------------------------------------------------------------------------|-----------------------------|-------------|
| Menu        |    | Menu / Home                 |             |
| Exit        |    | Exit / Cancel / Clear       |             |
| Up          |    | Up                          |             |
| Down        |    | Down                        |             |
| Left        |    | Left                        |             |
| Right       |    | Right                       |             |
| OK          |    | OK                          |             |
| Red/Format  |    | Red / Netflix / Search      |             |
| Green/Sound |    | Green / APP / Repeat        |             |
| Yellow/[ ]  |   | Yellow / YouTube / Repeat   |             |
| Blue/Timer  |  | Blue / Prime Video / Random |             |
| Violet/PC   |  | TV/Radio /                  |             |
| Stop        |  | Stop / Hold                 |             |
| Pause       |  | Pause / Step / Freeze       |             |
| CD          |  | Shift + 3                   |             |
| VID 1       |  | Eject / Surround            |             |
| Tape        |  | Shift + 5                   |             |























| Original | Replacement                                                                         | Original         | Replacement |
|----------|-------------------------------------------------------------------------------------|------------------|-------------|
| Power    |    | Power            |             |
| 1        |    | 1                |             |
| 2        |    | 2                |             |
| 3        |    | 3                |             |
| 4        |    | 4                |             |
| 5        |    | 5                |             |
| 6        |    | 6                |             |
| 7        |    | 7                |             |
| 8        |    | 8                |             |
| 9        |   | 9                |             |
| 0/--     |  | 0                |             |
| AV       |  | AV / Input / RDS |             |
| Mute     |  | Mute / Dimmer    |             |
| Vol+     |  | Vol+             |             |
| Vol-     |  | Vol-             |             |
| PR+      |  | CH+ / Page+      |             |
| PR-      |  | CH- / Page-      |             |


















| Original    | Replacement                                                                           | Original                    | Replacement |
|-------------|---------------------------------------------------------------------------------------|-----------------------------|-------------|
| Menu        |    | Menu / Home                 |             |
| Exit        |    | Exit / Cancel / Clear       |             |
| Down        |    | Down                        |             |
| Up          |    | Up                          |             |
| Left        |    | Left                        |             |
| Right       |    | Right                       |             |
| OK          |    | OK                          |             |
| Red/Format  |    | Red / Netflix / Search      |             |
| Green/Sound |    | Green / APP / Repeat        |             |
| Yellow/[ ]  |   | Yellow / YouTube / Repeat   |             |
| Blue/timer  |  | Blue / Prime Video / Random |             |
| Violet/PC   |  | TV/Radio /                  |             |
| Stop        |  | Stop / Hold                 |             |
| Pause       |  | Pause / Step / Freeze       |             |
| Play        |  | Play / Slow                 |             |
| >>/F.FWD    |  | >> / Tune+                  |             |
| <</REW      |  | << / Tune-                  |             |







| Original | Replacement                                                                         | Original         | Replacement |
|----------|-------------------------------------------------------------------------------------|------------------|-------------|
| Power    |    | Power            |             |
| 1        |    | 1                |             |
| 2        |    | 2                |             |
| 3        |    | 3                |             |
| 4        |    | 4                |             |
| 5        |    | 5                |             |
| 6        |    | 6                |             |
| 7        |    | 7                |             |
| 8        |    | 8                |             |
| 9        |   | 9                |             |
| 0/--     |  | 0                |             |
| AV       |  | AV / Input / RDS |             |
| Mute     |  | Mute / Dimmer    |             |
| Vol+     |  | Vol+             |             |
| Vol-     |  | Vol-             |             |
| PR+      |  | CH+ / Page+      |             |
| PR-      |  | CH- / Page-      |             |

| Original    | Replacement                                                                           | Original                    | Replacement |
|-------------|---------------------------------------------------------------------------------------|-----------------------------|-------------|
| Menu        |    | Menu / Home                 |             |
| Exit        |    | Exit / Cancel / Clear       |             |
| OK          |    | OK                          |             |
| Up          |    | Up                          |             |
| Down        |    | Down                        |             |
| Right       |    | Right                       |             |
| Left        |    | Left                        |             |
| Red/Format  |    | Red / Netflix / Search      |             |
| Green/Sound |    | Green / APP / Repeat        |             |
| Yellow/[ ]  |   | Yellow / YouTube / Repeat   |             |
| Blue/Timer  |  | Blue / Prime Video / Random |             |
| Violet/PC   |  | TV/Radio /                  |             |
| Play        |  | Play / Slow                 |             |
| >>/F.FWD    |  | >> / Tune+                  |             |
| <</REW      |  | << / Tune-                  |             |
| Rec         |  | Rec / Rec Mode              |             |
| Stop        |  | Stop / Hold                 |             |



