






































































Original	Replacement
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 TV / Radio	 TV/R
 Recall	 Pre Ch
 P.Mode	 Format
 S.Mode	 Dual
 Audio	 Shift + Dual

Original	Replacement
 Sleep	 Sleep
 Source	 AV
 CH +	 Ch +
 CH -	 Ch -
 Vol +	 Vol +
 Vol -	 Vol -
 Info	 Info
 Rec	 Rec
 R.List	 List
 Fav	 Shift + Pre Ch
 Guide	 Guide
 Up	 Up
 Right	 Right
 Down	 Down
 Left	 Left
 OK	 Ok
 Menu	 Menu





Original	Replacement	Original	Replacement
 Exit	 Exit	 Lang / Audio	 Smart
 I<< / Text	 I<<	 Red / D.Setup	 Red
 I<< / Text	 Text	 Red / D.Setup	 Options
 >>I / Hold	 >>I	 Green / D.Menu	 Green
 >>I / Hold	 Shift + Pause	 Green / D.Menu	 D. Menu
 << / Size	 <<	 Yellow / D.Title	 Yellow
 >> / Reveal	 >>	 Blue / D.Display	 Blue
 Play/Pause / Index	 Play		
 Play/Pause / Index	 Pause		
 Blue / D.Display	 Shift + Info		
 Stop / Subpage	 Stop		
 Stop / Subpage	 Shift + Subt		
 Open/Close / Time Shift	 Shift + Exit		
 Subtitle	 Subt		
 Repeat	 Shift + Text		
 Goto	 Shift + Guide		
 A - B	 Back		

