



Original	Replacement	Original	Replacement
	Power		Power
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Tv/Radio		TV/R
	Up		Up
	Down		Down
	Right		Right
	Left		Left

Original	Replacement	Original	Replacement
	OK/List		Ok
	Menu		Menu
	Exit		Exit
	Guide		Guide
	Recall		Back
	Green/FAV		Green
	Red/Audio/Subtitl		Red
	Yellow/UHF		Yellow
	Blue/i		Blue

